

ADJUSTING BRIGHTNESS




Guide for troubleshooting Galaxy Tab Active 2, 3, 5's


- 1 Tap the "i" icon at the bottom left.




- 2 Tap Settings.




- 3 Tap Display.




- 4 If prompted, toggle switch to allow permission, then tap back arrow.



- 5 Disable Auto Brightness, drag brightness level to preferred setting, and set Screen Timeout to preferred setting.



- 6 Once complete, adjusted brightness settings should look like the example below.



Document contains sensitive information - For internal use only

SCAN FLOWCODE
FOR MORE INFORMATION ON YOUR IN-CAB TECH

