

ADJUSTING TIME ZONE




Guide for troubleshooting Galaxy Tab Active 2, 3, 5's


1 Tap the "i" icon at the bottom left.




2 Tap **Settings**.




3 Scroll to the bottom (Swipe Up).




4 Tap **Date and time**.



5 Automatic date and time is enabled by default. To further adjust, **toggle switch**.



6 Success! Time zone can now manually be adjusted.



Document contains sensitive information - For internal use only

SCAN FLOWCODE
FOR MORE INFORMATION ON YOUR IN-CAB TECH



PRIVACY.FLOWCODE.COM