


GreenZone


mobileapp-help.netradyne.com/hc/en-us/articles/1500006299981-GreenZone

Your GreenZone Score is determined based on your driving performance. This score is an amalgamation of Alerts generated, Neutral Driving, and DriverStars. When your driving performance is good, your GreenZone Score increases, whereas when you generate alerts due to unsafe driving, your GreenZone Score decreases.

Time Period

The Daily, Weekly, or Monthly buttons allow you to view your driving performance for the selected duration. You can use the arrow buttons to select the required date, week, or month.





The Driver Report displays the following:

Your Score: GreenZone Score based on your driving performance.

Potential Score: Possible GreenZone Score if the Alerts were not generated.

High Impact Events: The alerts that impacted your GreenZone Score most are listed here. For example, an alert that was generated when you did not stop at a red light, which resulted in reduced GreenZone Score.

Total Minutes Analyzed: Displays the amount of time (in minutes) you drove the vehicle, including the time when vehicle was switched on but not moving.


Total Alerts: Displays total number of alerts generated for the selected duration.

Green Minutes %: Displays the number of minutes vehicle was driven without generating any alerts.

DriverStars: Displays the number of DriverStars awarded to you for the selected duration. DriverStars are awarded to recognize good driving performance. For example, if you create a space between your vehicle and the vehicle that cuts into your lane, this is a sign of positive driving behavior, and you will receive a DriverStar.

Average Following Distance: Average distance maintained between your vehicle and the vehicle ahead that is also in the same lane.

Driver Score chart: Displays a graphical representation of your GreenZone Score. You can view the following details:



- **You:** Represents your GreenZone Score.
- **Goal:** Represents the Fleet Goal. This is also a minimum score that needs to be achieved by all drivers in the Fleet.
- **Poor Performance:** Represents the GreenZone Score that is a minimum requirement to avoid getting rated as a poor performer.
- **Fleet Average:** Represents the average of the GreenZone Scores secured by all the drivers in the Fleet.

You can tap the legends located above the chart to filter the respective selection.

© 2024 Netradyne. Confidential Information of Netradyne, Inc.