
User manual



PRODUCT DIMENSIONS & SPECIFICATION

Product MaterialSuper Soft Silicone Shell

Power Source

5v USB Compartible Charging

Maximum Sound


Does not exceed 50 decibels and disappears in 1 meter

Water Resistance

100% Waterproof

Dual Function

Maximum pleasure & stress relive






WARNING Carefully read and understand the following instructions.


Introduction
Thank you for purchasing a quality product from GLAMM ITALIA S.R.L.

Please read this user manual carefully and keep it for future reference.

If you need assistance, please contact our technical support with the model number of your product.



User Manual



№JOY BOX

Charging Mode

- **1.** Attach the magnetic end of the supplied USB cable to the two metal contact points on the back of the device.
- 2. Plug the USB end into any USB port, such as a PC or wall adapter. The LED light in the button will flash red when the device is charging.
 - **3.** Charge the device until the emitted red light stops flashing and remains solid red. The device takes about 3 hours to fully charge.

Note: It is recommended to fully charge the device before first use for maximum experience.



Power on mode

- Press and hold the power button on the device for 3 seconds to turn on the device.
 The red light in the power button will turn on and begin to strike and vibrate, indicating that the vibrator is on.
- **2.** Press the button indicated on the device to cycle through the 7 vibration modes to stimulate the G-spot and clitoris.
- **3.** Press and hold the power button (©) on the device for 3 seconds to turn the device off. The red lights in the two buttons will turn off and the vibration will stop, indicating that the vibrator has been turned off.

Note: Please lubricate before using the product to get the best experience.





Cleaning and care information

- **1.** Use only a water-based lubricant with silicone-based devices, Never use silicone-based lubricants, massage oils or hand creams because they damage the silicone in your device. This can trap bacteria and break your toy.
 - Lightly clean the toy with mild soap and water after each use. Use Never use cleaners containing alcohol, benzine or acetone. They damage the toy.
 - **3.** Wipe with a clean cloth and allow to air dry completely before storing the toy in its box.
 - **4.** Storage should be in a cool, dark place to ensure product durability.
- **5.** Never store in direct sunlight or in a warm place, for example, in your car during the summer.
 - **6.** Keep out of reach of children and pets.





User information

Pursuant to art. 26 of Legislative Decree no. 49 of 14 March 2014 "Implementation of Directive 2012/19/EU on waste electrical and electronic equipment (WEEE)" and art. 9 of Legislative Decree no. 188 of 20 November 2008 "Implementation of Directive 2006/66/EC on batteries, accumulators and associated waste".

The symbol of the crossed-out wheelie bin shown on the equipment or on its packaging indicates that the product, at the end of its useful life, must be collected separately from other waste in order to allow for proper treatment and recycling.

The user must, therefore, deliver the equipment, which has reached the end of its useful life, free of charge, to the appropriate municipal centers for the separate collection of electrical and electronic waste.

Please note that the equipment contains the following types of accumulators that cannot be removed by the end user: Lithium battery accumulators 14650. These accumulators must be removed only by qualified professionals and must not be disposed of as unsorted municipal waste, being subject to separate collection in order to prevent damage to the environment and human health, in compliance with Directive 2006/66/EC and national

implementing laws.

The proper separate collection for subsequent recycling, treatment and environmentally compatible disposal of waste equipment, batteries or accumulators contributes to avoiding possible negative effects on the environment and human health and promotes the reuse and/or recycling of the materials from which the equipment and the batteries or accumulators are made.

Illegal disposal of the product and the batteries or accumulators contained therein by the user will result in the application of the sanctions set forth in current legislation.




Additional Information and Warranty

As our affiliated Paloqueth manufacturers, we as importers Glamm Italy s.r.l.
are committed to providing customers with the best
products and customer service available in the market today. Please note that all of our products
are covered by 24 months of
legal warranty or manufacturer's compliance from the date of your retail purchase. If you are not
satisfied with the performance of your product or your product does not function

adequately for any reason, please feel free to contact us at supportspaloqueth.com to make a warranty claim. Paloqueth is committed to be available if you need additional help or information about your purchase.

To take advantage of the commercial warranty and learn more refer to the purchase marketplace.







IMPORTED BY:

GLAMM ITALIA S.R.L.

Via Marcello Finzi 597 41122 Modena (MO)

PEC: glammitaliasrl@pec.it Number REA :MO - 428477 P.IVA : 03919930366

N° iscr reg. pile - IT20120P00006665 N° iscr reg. AEE - IT20090000012404

MANUFACTURED IN:

Shenzhen Weiweima Techonology Co., Ltd. 301, No. 2 Building, Lijincheng Tech Ind. Zone, Yousong Community, Longhua Street, Longhua Dist., Shenzhen, Guangdong, China

Made in China

