

ADJUSTING FONT SIZE




Guide for troubleshooting Galaxy Tab Active 2, 3, 5's


1 Tap the "i" icon at the bottom left.




2 Tap **Settings**.




3 Tap **Display**.




4 If prompted, **toggle switch to allow permission**, then tap back arrow.



5 Swipe up (scroll to the bottom).



6 Use **lever at the bottom** to adjust font size as needed (this will affect all apps, such as KT Mobile, Pointe, Geotab, etc.)



Document contains sensitive information - For internal use only

SCAN FLOWCODE
FOR MORE INFORMATION ON YOUR IN-CAB TECH

