

















Theater and TV Instructions

It's Showtime!

To Watch A DVD

-  Turn on the Projector.
-  Turn on the Onkyo receiver.
-  Select BD/DVD on the Onkyo receiver.
-  Turn on the DVD player.
-  Add your DVD and close.
-  Use the DVD remote to control the viewing.
-  Use the Onkyo receiver remote to control the volume.

To Watch Streaming or Cable

-  Turn on the Projector.
-  Turn on the Onkyo receiver.
-  Select CBL/SAT on the Onkyo receiver.
-  Select the app you want to watch using the Roku (i.e. Netflix or Spectrum for cable).
-  Log into your streaming app if required (don't forget to log out before you leave!).
-  Use the Roku remove to control the viewing.
-  Use the Onkyo receiver remote to control the volume.

No remote? Use the Roku App!

Download the Roku – Official Remote app to your phone and operate any Roku TV!

- ✓ Make sure the TV is powered on and your phone is connected to the wifi.
- ✓ Open the "Devices" option in the app and select the TV/Roku device you are trying to operate.
- ✓ Tap "Remote" and operate as normal.