

Alkon Corporation.
Lab Air Dryer Preventive Maintenance Instructions

For Machine(s): 8577 (TA-11)

MONTHLY TASKS TO BE COMPLETED

MACHINE CARE

- CLEAN CONDENSOR COIL
- CHECK AUTOMATIC DRAIN IS DISCHARGING
- BLOW DOWN SEPARATOR BY PUSHING TEST BUTTON
- CHECK PRESSURE DROP ACROSS DRYER

ANNUAL TASKS TO BE COMPLETED

MACHINE CARE

- REPLACE FILTER ELEMENT
- REUBUILD DRAIN MECHANISM